



ELITE SERIES BEACON - WHITE WORK LIGHT

GOOD TO KNOW

PROTECT YOUR DEVICE

- gadevice.com/warranty

GET TO KNOW YOUR DEVICE

- gadevice.com/learn

FEATURES



MAGNET MOUNT



EXTREME BATTERY LIFE



360° HIGH VISIBILITY



BUILT TOUGH



IP68 RATED



RECHARGEABLE

GETTING STARTED

INITIAL ACTIVATION

- Hold down the Front and Rear buttons for 2 seconds - work light turns ON
- OR - plug your device in - work light will flash
- Unit turns on at Max brightness

SLEEP MODE / POWER DOWN

- Hold down the Front and Rear buttons for 3 seconds - work light flashes 3 times - unit is OFF. Follow same process to power unit ON.

CHARGING (charge time dead to full - approx. 2 hours)

- Open sealed door on the bottom of the device and plug in USB cable. Charging can be with any USB 2000mA ac adapter used with cell phones.

Note: Work light single flashes when charging, flashes twice when fully charged.

ELITE SERIES OPERATION: BEACON - WHITE WORK LIGHT

TOP LED
Dedicated button for spotlight lens
• 1st Press: Constant On
• 2nd Press: Constant Flashing
• 3rd Press: OFF

REAR LEDs
• 1st Press: Constant On
• 2nd Press: Constant Flashing
• 3rd Press: Scrolling Sequence (Front Looking Shown Left to Right)
• 4th Press: OFF
• **Hold:** Battery Level Indicator

BATTERY LEVEL
Full Charge: ■■■■■
Half Charge: ■■■
Low Charge: ■

WORK LIGHT
• 1st Press: (I) White LED On
• 2nd Press: OFF
• **Front / Rear Hold:** Standard Operating Mode (All Front LED's On, Rear LED's Flashing)

TETHER HINGE
• Tether Accessory Attachment (Tether Sold Separately)

GA EMERGENCY MODE
• 1st Press: Front & Rear LEDs Flashing
• 2nd Press: OFF
• **Hold:** All LEDs Flashing (Double Press Turns Off All LEDs)

BRIGHTNESS SETTINGS
• 1st Press: Max
• 2nd Press: High
• 3rd Press: Medium
• 4th Press: Low
• **Hold ON/OFF** for SOS Signaling

FRONT LEDs
• 1st Press: Constant On
• 2nd Press: Constant Flashing
• 3rd Press: Scrolling Sequence (Front Looking Shown Left to Right)
• 4th Press: OFF



IMPORTANT SAFETY NOTICE:

The Guardian Angel® has **Neodymium Magnet** built into the product for mounting purposes. Never allow neodymium magnets near a person with a pacemaker or similar medical aid. The strong magnetic fields of the magnet can affect the operation of such devices. Neodymium magnets are extremely strong, and must be handled with care to avoid personal injury. Fingers and other body parts can get severely pinched between two attracting magnets. Neodymium magnets can also damage magnetic media such as floppy disks, credit cards, magnetic ID cards, cassette tapes, video tapes or other such devices. They can also damage televisions, VCRs, computer monitors and other CRT displays. Never place neodymium magnets near electronic appliances. Children should not be allowed to handle neodymium magnets as they can be dangerous. Small magnets pose a choking hazard and should never be swallowed or inserted into any part of the body. Seek immediate medical attention if magnets are swallowed or inhaled. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. For a full list of safety notices and terms, please visit <http://www.guardianangeldevices.com/terms>